


■NOTES

- Unplug the instrument when not in use.
- When storing the unit for long periods of time, disconnect the battery.
- You will hear some loss of level and distortion when the battery begins to run down.
- When using external power source, we recommend you use Ibanez AC adaptor AC-109.
- Do not remove the screws on bottom.

■SPECIFICATIONS


- Input Impedance 500K ohms
- Output Impedance 10K ohms
- Maximum Output Level 0 dBm
- Maximum Gain +40 dB
- Equivalent Input Noise -100 dBm (IHF-A)
- Power Supply One 9 Volt Battery or external AC adaptor (AC-109)
- Size 125mm, 4.9" (D) x 70mm, 2.8" (W) x 52mm, 2" (H)
- Weight 550 g, 1.2 lbs

OWNERS MANUAL



OVER DRIVE II

OD-855




Ibanez

■ FEATURES

- Produces a wide range of distortion sounds from soft to hard. A newly developed tone control arrangement allows increased control over the distortion sound for increased versatility.
- FET electronic switching provides clickless, popfree switching. (Q-1 "Quiet One" switch)
- Battery can be changed without tools.
- LED indicator shows status of effect and battery condition.
- When using the unit for long periods of time, you can use external AC power by connecting the adaptor to the EXT. POWER jack.
- Zinc die cast construction and rugged rubber stopper assures durability.

■ OPERATION



- ① Connect the input jack to your instrument. The circuit is automatically turned on when a plug is inserted.
- ② **DISTORTION** — Depth of the distortion is increased as control is turned CW (clockwise).
- ③ **TONE** — Center position is flat. Turning CW (clockwise) increases highs for that biting edge. Turning CCW (counter-clockwise) cuts highs for more mellow distortion.
- ④ **LEVEL** — Controls output level. Usually set at 1:1 NORMAL/EFFECT ratio.
- ⑤ Soft touch FET electronic switch changes EFFECT/NORMAL.
- ⑥ LED indicator comes on when effect is on. If it is dim or does not light, replace the battery.
- ⑦ **EXT D.C.** — When using external D.C. supply, internal batteries are switched off.

■ CHANGING THE BATTERY

- ① Push the tab marked "OPEN" and lift up.
- ② Replace the battery as shown in figure 2.
- ③ Put the battery cover into the groove and push to the end.




Fig. 1




Fig. 2




Fig. 3