

Fuzz - Sustainer





Technical Data:

Completely transistorized.

Adjustable volume and distortion intensity.

Footswitch for normal sound and distor-

On- and off switch, built-in into the "Output" bush.

Voltage: 9 Volt transistor battery (when changing the battery, take off the bottom plate - remove spent battery at once).

Durable leather-patterned casing, black.

Dimensions: 285 x 110 x 80 mm

Weight: 1000 gramme

Operating Instruction:

Connections:

From the bush "Input" the cable runs to the instrument. From the bush "Output" a cable runs to the amplifier (if exchanged, no sound).

Control Possibilities:

Position Effect:

By the sweep volume and distortion are adjusted.

By the control "Intensity" the distortion is adjusted from faint to strong.

Position Original:

By the change-over switch "Fuzz" you get the function of a footswell - the volume of it is adjustable by the sweep.

Important

By connection the cable to the "Output" bush, the battery is switched on. Take out the plug when the unit is not used.